


Mustang Portable Heavy Duty Extractor

1500 PSI

Owner's Manual



IMAGES AND ILLUSTRATIONS ARE FOR REFERENCE ONLY.
ACTUAL PRODUCTS MAY NOT BE EXACTLY AS SHOWN.

1633 WEST 134th. STREET GARDENA, CA 90249-2013

TEL: 310 323 1134 FAX: 310 323 8397

WWW.TIMBUCKTOOMFG.COM

© All rights reserved

CAUTION

GENERAL PRECAUTIONS FOR SINGLE AND DUAL POWER CORD EXTRACTORS:

Single Power Cord Extractors

Make sure the extractor is plugged into an electrical outlet with the same voltage as shown on the extractors

Dual Power Cord Extractors

Make sure the power cord is plugged into an electrical outlet with the appropriate voltage. (As shown on the extractor). Each power cord must be on separate circuits. To test if the extractor is on two separate circuits press the "Circuit Test" switch located on the switch plate. If the green light is illuminated it will confirm that the extractor is on two separate circuits. If the green light is not illuminated this indicates that the extractor is on the same circuit, and that the user must find an additional circuit to plug into.

Warning!

This extractor is designed for use on carpet, floor and upholstery applications as per instructions written in this manual. Any deviation from its proper use or purpose and the consequential damage that may occur is the sole responsibility of the end user.

Do not attempt to repair the extractor. See your authorized service dealer.

Do not expose extractor to extreme temperatures.

Do not use unauthorized replacement parts.

This extractor was tested before shipping and antifreeze may remain in the plumbing system. The user must flush out antifreeze before use. Make sure to use antifreeze if storing the extractor in extremely cold weather.

TABLE OF CONTENTS

| | |
|--|----|
| CAUTION | 2 |
| TABLE OF CONTENTS | 3 |
| LIMITED WARRANTY | 4 |
| WARRANTY REGISTRATION | 5 |
| Owner's warranty information | |
| SAFETY INSTRUCTIONS | 7 |
| EXTRACTOR OVERVIEW | 8 |
| ASSEMBLY | 9 |
| Connect power, Connect hose | |
| OPERATING THE EXTRACTOR: | 10 |
| Before operating | |
| Operating | |
| After operating | |
| PREVENTATIVE MAINTENANCE | 12 |
| HOW TO: | 14 |
| How to use attachment tools | |
| How to bleed the system | |
| - system without electric instant water heater | |
| - system with electric instant water heater | |
| Auto dump pump | |
| Auto fill | |
| OPTIONS: | 18 |
| Chemical feed & Mixing system | |
| Adjustable chemical feed system | |
| Metering tips preset chemical feed system | |
| TROUBLESHOOTING: | 21 |
| Electrical system | |
| Pump system | |
| Vacuum system | |
| Heating system | |

LIMITED WARRANTY

All equipment and accessories are thoroughly inspected and tested before leaving the factory. They are warranted to be free of defects from workmanship and materials for one year from date of original purchase. (proof of purchase is required).

Labor: 90 days from initial purchase

Parts: 1 year, excluding normal wear and tear items

Heavy duty Fiber composite body: 20 years limited warranty

Polyethylene body: 5 years limited warranty

Should any trouble develop during this period, please contact your dealer or manufacturer to receive a Return Guarantee Authorization number (RGA #). Return the parts or extractor that need to be replaced. If after an inspection it is determined to be under warranty, the factory will repair or replace (manufacturer's discretion) the parts or equipment and return parts or equipment at no charge. Note: Credit, repair or replacement will not be given to any parts or equipment without the above mentioned RGA#.

Proof of purchase is necessary to establish the date of the original sale. Receipt of purchase or warranty registration can be used as proof of purchase. It is extremely important to register your purchase by sending Timbucktoo MFG., Inc. the warranty registration form within 10 days of purchase (Page 5).

This warranty is in lieu of all other warranties expressed or implied, and no person is authorized to give any other warranty, assume obligation or liability on the manufacturer's behalf.

This Warranty does not apply when:

- Repairs that are required because of normal wear and tear
- Repairs have been made or attempted by others
- Items have been abused, misused or improperly maintained
- Modifications or alterations have been made to the equipment

LIMITATION OF REMEDY:

In no event shall seller be liable for any incidental, consequential or special damages of any kind or nature whatsoever. Including but not limited to lost profits arising from or in anyway connected with this agreement or items sold hereunder, whether alleged to arise from breach of contract, express or implied warranty, or in tort, including without limitation, negligence, failure to warn or strict liability.

ENTIRE AGREEMENT / GOVERNING LAW:

This agreement and warranty shall be governed in all respects by the law of the State of California. No actions arriving out of the items sold hereunder or this Agreement may be brought by either party more than two (2) years after the cause of action occurs. All mediation or litigation will take place in the County of Los Angeles in California.

WARRANTY REGISTRATION

PLEASE SIGN AND MAIL WITHIN 10 DAYS FROM THE SALE DATE FOR VALID WARRANTY

PLEASE PRINT OR TYPE (SEND TO DEALER)

PURCHASED FROM (DEALER NAME):

ADDRESS:

CITY, STATE, ZIP:

TELEPHONE:

DATE OF PURCHASE:

SERIAL NUMBER:

MODEL NUMBER:

.....

PLEASE PRINT OR TYPE (SEND TO TIMBUCKTOO MFG., INC.)

DEALER NAME:

ADDRESS:

CITY, STATE, ZIP:

DATE SOLD:

PURCHASER'S NAME:

ADDRESS:

TELEPHONE:

DATE OF PURCHASE:

SERIAL NUMBER:

MODEL NUMBER:

Signature:

Print Name:

OWNER'S WARRANTY INFORMATION

DATE OF PURCHASE:

SERIAL NUMBER:

MODEL NUMBER:

PURCHASED FROM (DEALER NAME):

ADDRESS:

CITY, STATE, ZIP:

TELEPHONE:

KEEP FOR YOUR OWN RECORDS

BLANK PAGE

SAFETY INSTRUCTIONS

WARNING!


When using an electrical appliance, basic precautions should always be followed.

To reduce the risk of fire, electric shock or injury following these tips:


1. Do not leave appliance plugged in. Unplug from outlet when not in use.
2. Electric shock could occur if used outdoors or on wet surfaces.
3. Keep away from children. Extractor is not to be used as a toy.
4. Use only as described in this manual. Use only manufacturer's recommended parts.
5. Do not use extractor with damaged power cords.
6. Do not abuse the power cord. Do not pull or carry extractor with the power cord. Do not use the power cord as a handle. Do not close doors on the power cord. Do not pull power cord around sharp edges or corners. Do not run the extractor over the power cord. Do not keep power cords around heated surfaces.
7. Do not unplug by pulling on electric power cord. To unplug, grasp the plug, not the electric power cord.
8. Do not handle plug or appliance with wet hands.
9. Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair and anything that may reduce air flow.
10. Keep hair, loose clothing, fingers and all parts of body away from openings and moving parts.
11. Do not pick up anything that is burning or smoking, such as cigarettes, matches or hot ashes.
12. Do not use extractors without filters.
13. Turn off all controls before unplugging from electric outlet.
14. Use extra care when cleaning on stairs.
15. Always wear safety equipment and appropriate clothing when operating the extractor.
16. Do not use extractor to pick up flammable or combustible liquids such as gasoline or use in areas where such items may be present.
17. Connect to a properly grounded electric power outlet only.
18. Do not attempt to service the extractor while appliance is plugged in.

EXTRACTOR OVERVIEW

image 8.1




(*) = standard equipment for unit with 500 psi pump



TF105110
solution filter
inside solution tank

image 8.2

image 8.4



PM10150
wet vacuum filter
inside recovery tank

image 8.3

ASSEMBLY

CONNECT ELECTRIC POWER CORD

Protect the ground plug. This plug is to be used with a proper grounding type (three prong) receptacle. Do not break off or pull out the grounding blade. (see below image)




image 9.1

FLIP OPEN & PUMP CAP

1. Locate the pump, on the right side toward the front of the unit. (see image 9.4)
2. Remove the red oil cap plug (shipping cap, see image 9.2) with a 3/4" open-end wrench and check oil reservoir for proper level. Oil level should be to middle of clear tube. (see image 9.2)
3. If need more, use 80 wt., non-detergent oil. Replace filter plug/black dipstick cap. (see image 9.2 and 9.3) Do not tilt the machine over 30 degrees.
4. In case need to tilt over 30 degrees, we suggest to replace with red oil cap plug (shipping cap, see image 9.2) before tilt or move around.
5. If spill, make sure to clean and add back 80 wt., non-detergent oil to middle of clear tube before use it.
6. Replace back panel, being sure to align openings with plumbing outlets. Replace screws to secure panel. Close bleeder valve, and put back bolts on bottom of machine.




image 9.2

oil level should be in middle of filter plug/black dipstick cap



image 9.3




image 9.4

OPERATING THE EXTRACTOR

BEFORE OPERATING:

Read the manual carefully and completely before attempting to operate the extractor. Make sure the unit is plugged into an electrical outlet with the same voltage as shown on the extractor.

1. When plugging in a dual power cord extractor (see below image 10.1); each cable should be on separate circuits. When this is accomplished a green light will turn on when the “Circuit Test Switch” (see image 10.2) is pressed on the switch plate. If the light does not turn on, this indicates that you are not on two separate circuits and are increasing your chance of a circuit blowout.
2. Always thoroughly pre-vacuum the surface to be cleaned. Using an upright vacuum cleaner (or the extractors dry vacuum with optional dry attachment).
3. Pre-spray the cleaning area with recommended cleaning solution for the best results.
4. Fill solution tank with clean water.
5. Connect both the vacuum hose and solution hose to proper locations. See image on “Assembly” page. (see image 10.3)
6. Make sure the drain valve is closed and the recovery tank lid is secured before turning on the vacuum and pump switches. (see image 10.3)



image 10.1

■ two electric power cables
(see image 10.2)




image 10.2

“Circuit test” switch next to the green light, push that switch and the green light should glow, if not you don’t have two sepeate circuits.




image 10.3

OPERATING THE EXTRACTOR

OPERATING:

1. Start and continue cleaning until the clean water tank is empty and/or recovery tank is full or until cleaning job is done.
2. If foam is detected in the recovery tank and hose, use a defoamer to prevent damage to the vacuum motors.

AFTER OPERATING:

1. Turn off all the switches and disconnect electric power cord from power plug, then empty the recovery tank into a bucket or another proper drain area. (see below image 11.1)
2. Remove remaining water from clean water tank, disconnect the vacuum hose from wand and insert the vacuum hose into clean water tank. Vacuum out all the excess water. (see below image 11.2.)
3. Drain and thoroughly clean the recovery tank. At this point the tank can be rinsed while dumping.
4. The vacuum filter (wet filter) and ball float cage have to be rinsed and cleaned thoroughly when it's still wet. (see below image 11.3.) See "Preventative Maintenance" page. Wrap power cords around handle for storage. Do not use solution or recovery tanks for storage, extractor can be damaged.

Consult your sales representative for more information on cleaning methods.




image 11.1




image 11.2



image 11.3

PM10150
vacuum filter
and ball float
cage in
recovery tank

PREVENTATIVE MAINTENANCE

AFTER EACH USE: CLEAN, LUBRICATE, ETC...

1. Thoroughly clean all equipment and accessories after each use.
 - a. Rinse solution tank, recovery tank, and hoses with clean water.
 - b. Flush entire solution system with clean water. This includes all solution hoses and attachment tool. Do not allow liquid with cleaning chemicals to remain in the equipment.
 - c. Clean all filters (see below images: solution tank filter, solution line filter, vacuum filter, auto dump pump filter)
2. Lubricate all quick connects as needed.
3. Do not use the same container to fill the solution tank that is used to empty the waste tank. This would result in putting dirt and debris into the solution lines that will block filters, orifices, and generally degrade the systems.
4. Keep equipment out of extreme temperatures. (i.e. Freezing temperatures will make water expand, and will damage pump, fittings, valves, etc.)
5. Turn off the extractor whenever not in use. Do not walk away from an extractor, while unattended the extractor can cause excessive pressure that is not good for it.
6. Check for loose or frayed wires.

image 12.1

Solution tank filter located in solution tank (all standard models)




image 12.2

Solution line filter (1500 psi model extractor)





image 12.3

Auto Dump pump and filter



PREVENTATIVE MAINTENANCE CONT.

A clean vacuum filter (*) must be installed in the recovery tank at all times to protect the motor. (See below image 13.1)

Serious damage to vacuum motors will occur when vacuum filter is not installed. (See below image 13.2)

image 13.1





image 13.2



HOW TO


HOW TO USE ATTACHMENT TOOL

BETTER TECHNIQUE WILL HELP WITH DRY TIME, CARPET LIFE, AND OVERALL COST.



1. To clean, Pull the tool over the carpet with solution control valve lever pressed. (image 14.2, 14.1, 14.3, 14.4)
Press the lever only while pulling back on the wand. (image 14.3, 14.2) Pull the tool with the valve lever pressed to insure the best results.
2. Release the solution control valve lever (image 14.4, 14.1) and pass the tool over the dampened area once or twice by pulling or pushing the tool back and forth. Repeat the procedure if necessary.

NOTE: The weight of the tool and the vacuum suction are sufficient to obtain idea results. Additional physical pressure is unnecessary.

Continue cleaning until the recovery tank becomes full (or whenever the job is done).



Press the lever to open the valve



15

HOW TO

HOW TO BLEED

WITHOUT ELECTRIC INSTANT WATER HEATER:

1. Fill solution tank with clean water.
2. Connect desired tool and extractor with vacuum hose and solution hose.
3. Turn pump switch to "ON".
4. Open trigger valve from your attachment tool (See image 15.1), and spray until all air is out from the solution system. (See image 15.2) It might take 2-4 minutes depending on the jet size from the attachment tool.

WITH ELECTRIC INSTANT WATER HEATER:


WARNING: DO NOT TURN ON THE HEATER until you have following steps.

1. Fill solution tank with clean water.
2. Connect desired tool and extractor with vacuum hose and solution hose.
3. Turn pump switch to "ON".
4. Open trigger valve from your attachment tool (See image 15.1), and spray until all air is out from the solution system. (See image 15.2) It might take 2-4 minutes depending on the jet size from the attachment tool.
5. Turn heater switch on and wait approximately 3-4 minutes to heat up. Now you are ready to use your extractor with IN-LINE heater.


DID YOU KNOW?

The quickest way to bleed air out is taking all the jets out and then following steps 1 through 4 before replacing the jets.

image 15.1



Press the lever to open the valve



Air is out from
the solution system






image 15.2

16 HOW TO AUTO DUMP PUMP

1. Fill solution tank with clean water.
2. Connect desired tool and extractor with vacuum hose and solution hose.
3. Remove auto dump pump connect cap and connect auto dump hose. See image 20.1. (available longer optional dump hose)
4. Make sure manual drain valve is closed.
6. Turn pump, vacuum, and optional auto dump switches to "ON".
7. Start and continue cleaning until the clean water tank is empty and/or cleaning job is done.
8. Turn off all the switches and disconnect electric power cord from power plug, then empty the left over recovery tank into a bucket or another proper drain area.



17

HOW TO

AUTO FILL

1. Connect the end of clean IN-LINE hose to water faucet, (Faucet Adapters may be needed). See image 17.3.
 2. Then, connect the end with female quick connect to WATER IN (Automatic Fill) at extractor. See image 17.2. Turn the water faucet open. Let the solution tank fill up. No need to turn off water faucet until cleaning job is completed.
- NOTE: 1. If IN-LINE hose is dirty or not used recently, clean before use.
2. Water needs to be flowing into the extractor constantly while operating.




image 17.1




image 17.2

Connect the end with a female Q.C. to the water in (Auto Fill System) on the extractor

enlarged view of water faucet




image 17.3

19 OPTIONS

1. ADJUSTABLE CHEMICAL FEED SYSTEM

NOTE: You may pre-spray your cleaning area with a pre-spray solution prior to extracting or you may use the CHEMICAL FEED AND MIXING SYSTEM to mix in the cleaning solution automatically with water while cleaning.

To use the ADJUSTABLE CHEMICAL FEED AND MIXING SYSTEM, have a bottle or bucket of cleaning solution ready. (See image 19.4). If you are using a cleaning chemical in powder form, mix it with water thoroughly, make sure it is fully dissolved. Any undissolved powder can clog up the flowmeter, spray jets, and other parts on the extractor damaging them in the process.

- A. Place the bottle or pail of cleaning solution to the side of the extractor. Put the end of CHEMICAL FEED LINE all the way to the bottom of the bottle or bucket of cleaning solution. (See image 19.4). If the CHEMICAL FEED LINE is not fully submerged in the solution, air can get into the system and it may disable it.
- B. Turn pump switches "ON".
- C. Open the adjustable flowmeter fully by turning it counter clockwise. (See image 19.1 and 19.2)
If there is any air in the system, you will see air bubbles in the adjustable flowmeter and the ball inside will be bobbing up and down. (See image 19.2) Then, pull the trigger valve from wand or any attached tools to let the air out. (See the "How to Bleed" page)
- D. Adjust the Adjustable flowmeter according to the chart. (See image 19.3) Mixture rate should be based on the condition of the carpet or upholstery you are cleaning. When setting the flowmeter, open the solution valve on the wand.






image 19.3

| SCALE | WATER:CHEMICAL |
|-------|----------------|
| 1 | 60:1 |
| 2 | 30:1 |
| 3 | 20:1 |
| 4 | 15:1 |
| 5 | 12:1 |

(EXAMPLE: MIXTURE RATE:
SCALE 1=60 GALLON OF WATER TO 1 GALLON OF CHEMICAL)



IMAGES AND ILLUSTRATIONS ARE FOR REFERENCE ONLY. ACTUAL PRODUCTS MAY NOT BE EXACTLY AS SHOWN.

20 OPTIONS

2. METERING TIPS PRESET CHEMICAL FEED SYSTEM

ABOUT:

Same operation and setup as ADJUSTABLE CHEMICAL FEED SYSTEM, but preset chemical feed system do not use chemical feed adjustable flowmeter. (See images on "ADJUSTABLE CHEMICAL FEED SYSTEM" page)

The metering tips preset chemical feed rate is controlled by a metering tip (different size) screwed into the metering barb on the side of the unit. (see image 20.1, and the arrow)

The feed rates can be changed by using different size metering tip which is available with the kit.

To select a proper size metering tip for the desired dilution ratio refer to the chart. (see image 20.3)

Can be found metering system in between solution tank and the pump plumbing system.

TO USE:

Have a bottle or bucket of cleaning solution ready. If you are using a cleaning chemical in powder form, mix it with water thoroughly and make sure it is fully dissolved. Undissolved powder can clog up the spray jets and other parts on the unit damaging them in the process.

A. Place the bottle or bucket of cleaning solution to the side of the extractor. Put the end of CHEMICAL FEED LINE all the way to the bottom of the bottle or bucket of cleaning solution. (see image 20.2). If CHEMICAL FEED LINE is not fully submerged in the solution, air can get into the chemical feed and mixing system and it may disable the system. (see images on "CHEMICAL FEED AND MIXING SYSTEM PAGE")

B. Turn chemical feed switch on.




image 20.2

image 20.1

metering preset
chemical feed
system tips

DEMA ENGINEERING COMPANY
100-15K METERING TIP KIT FOR 1/2" ROSE BARRIS
10015 Hwy 100, St. Louis, MO 63122
Phone: (314) 963-8151 Toll Free: (800) 325-5362 Fax: (314) 963-8151

| PROPORTIONER MODELS (1:1) & (1:1.5)1/2" GPM (1.1) & (1.5) | | SPRAY CLEAN DIRECTORS S0001A 2.5 GPM & 2.5 GPM (1.5) & (1.5) | |
|--|-------|--|-------|
| TIP | RATIO | TIP | RATIO |
| Tan | 102:1 | Tan | 102:1 |
| Orange | 75:1 | Orange | 75:1 |
| Turquoise | 60:1 | Turquoise | 60:1 |
| Pink | 43:1 | Pink | 43:1 |
| Light Blue* | 33:1 | Light Blue* | 33:1 |
| Brown | 28:1 | Brown | 28:1 |
| Red | 22:1 | Red | 22:1 |
| White | 18:1 | White | 18:1 |
| Green | 16:1 | Green | 16:1 |
| Blue | 13:1 | Blue | 13:1 |
| Yellow | 9:1 | Yellow | 9:1 |
| Black | 6:1 | Black | 6:1 |
| Purple | 5:1 | Purple | 5:1 |
| Gray | 4:1 | Gray | 4:1 |
| None | 3.6:1 | None | 3.6:1 |

From 1/2" GPM
10015 Hwy 100, St. Louis, MO 63122
Phone: (314) 963-8151 Toll Free: (800) 325-5362 Fax: (314) 963-8151

image 20.3

INJECTION RATES

1 GPM/3.8 LPM

| TIP | RATIO | oz/gal. | mL/L |
|-------------|-------|---------|-------|
| Tan | 102:1 | 1.25 | 7.8 |
| Orange | 75:1 | 1.70 | 10.5 |
| Turquoise | 60:1 | 2.15 | 13.3 |
| Pink | 43:1 | 3.00 | 18.6 |
| Light Blue* | 33:1 | 3.90 | 24.2 |
| Brown | 28:1 | 4.55 | 28.2 |
| Red | 22:1 | 5.80 | 36.0 |
| White | 18:1 | 7.00 | 43.4 |
| Green | 16:1 | 7.90 | 49.0 |
| Blue | 13:1 | 9.80 | 60.8 |
| Yellow | 9:1 | 14.80 | 91.8 |
| Black | 6:1 | 20.15 | 124.9 |
| Purple | 5:1 | 27.80 | 172.4 |
| Gray | 4:1 | 31.60 | 195.9 |
| None | 3.6:1 | 35.00 | 217.0 |

IMAGES AND ILLUSTRATIONS ARE FOR REFERENCE ONLY.
ACTUAL PRODUCTS MAY NOT BE EXACTLY AS SHOWN.

TROUBLE-SHOOTING

TROUBLE-SHOOTING

| ELECTRICAL SYSTEM | | |
|--|---|--|
| PROBLEM | POSSIBLE CAUSE | HOW TO REPAIR |
| No electrical power (Component or extractor not turning on) | <ol style="list-style-type: none"> 1. Check the outlet & the plug 2. Damage cord 3. Circuit breaker off or fuse blown | <ol style="list-style-type: none"> 1. Plug in properly 2. See authorized repair person 3. Flip circuit breaker on or replace fuse. Unplug other equipment using the same circuit. Make sure cords are plugged into proper amp circuits. |
| Switch is turned on, power is intermittent to all motors | <ol style="list-style-type: none"> 1. Faulty electrical cable 2. Defective switch 3. Loose terminal or corroded connector | <ol style="list-style-type: none"> 1. to 3.: See authorized repair person |
| Electric shock | <ol style="list-style-type: none"> 1. Equipment or electric cord not grounded | See authorized repair person |
| PUMP SYSTEM | | |
| Pump motor stopped | <ol style="list-style-type: none"> 1. Pressure build up cause by jet clogged. 2. Thermal overload (over heated) 3. Damaged motor or rectifier 4. Pump switch defective 5. Loose wire connection 6. Pump pressure switch defective 7. Faulty motor | <ol style="list-style-type: none"> 1. Released pressure by opening up (press) the lever on the Wand. 2. Turn off the pump and heater switch and wait 20-30 minutes 3. to 7: See authorized repair person |
| Loss of pump pressure with wand valve open and/or uneven or weak spray from the jet tips | <ol style="list-style-type: none"> 1. Clogged or dirty spray tip 2. Accumulated dirt in solution line 3. Dirty or clogged filters 4. Pump check valve worn or dirty 5. Malfunction in the wand valve 6. Hose quick connect bad or clogged with foreign object | <ol style="list-style-type: none"> 1. Clean jets and screens 2. Flush system w/water 3. Clean 4. to 6: See authorized repair person |

TROUBLE-SHOOTING

| VACUUM SYSTEM | | |
|---|---|--|
| PROBLEM | POSSIBLE CAUSE | HOW TO REPAIR |
| Vacuum motor on with little or no vacuum or suction at wand/ upholstery tool | 1. Lid is not properly closed 2. Drain hose/valve not connected/ closed 3. Hose or wand clogged 4. Accumulated dirt on the ball float cage and filter 5. Worn out lid gasket 6. Lint and dirt build-up on wand 7. Damaged vacuum hose 8. Loose or no vacuum hose connection inside the extractor 9. Foreign object accumulated in vacuum fans | 1. Close the lid 2. Connect hose or close optional drain valve 3. Clean hoses and wand 4. Clean or replace the filter 5. Replace the gasket 6. Clean the wand 7. Replace 8. See authorized repair person 9. See authorized repair person |
| Vacuum motors run intermittently | | See authorized repair person |
| ETC... | | |
| PROBLEM | POSSIBLE CAUSE | HOW TO REPAIR |
| No water from the jet | 1. Extractor not plugged in (or circuit breaker off) 2. Switch is not turned on (bad switch?) 3. Empty solution tank 4. The hose is not connected properly | 1. Plug in working outlet 2. Turn the switch on. See authorized repair person for new switch 3. Fill the solution tank with water 4. Connect hose properly |
| Water or foam coming out from exhaust | 1. Over foaming of water in recovery tank 2. Elbow fitting in recovery tank pointing wrong direction (i.e. pointed toward the ball-float cage) 3. No ball-float cage 4. Too much water in the recovery tank | 1. Put defoamer in the recovery tank or put it in the end of vacuum hose with vacuum motor running 2. Point elbow away from ball-float cage 3. Install ball-flat 4. Drain the recovery tank |
| CAUTION: 1. DISCONNECT POWER CORDS FROM THE OUTLET BEFORE DOING ANY MAINTENANCE WORK. 2. WHEN ELECTRIC POWER IS ON PROTECT YOURSELF FROM ELECTRIC SHOCK & HEAT | | |

TROUBLE-SHOOTING

| | HEAT SYSTEM | |
|--|---|---|
| PROBLEM | POSSIBLE CAUSE | HOW TO REPAIR |
| Water not heating up | <ol style="list-style-type: none">1. Air in the heater2. Bad thermostat3. Heating element burned out4. Safety valve open | <ol style="list-style-type: none">1. Bleed (See "How to bleed" page)2. Replace3. Replace4. Check safety valve and close it |
| CAUTION: <ol style="list-style-type: none">1. DISCONNECT POWER CORDS FROM THE OUTLET BEFORE DOING ANY MAINTENANCE WORK.2. WHEN ELECTRIC POWER IS ON PROTECT YOURSELF FROM ELECTRIC SHOCK & HEAT | | |

WARNING: This product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

ADVERTENCIA: Este product contiene substancias quílicas reconocidas par el estado de California como causantes de cancer, anomalias congenitas y otros danos reproductivos.



Manufacturer of commercial & environmental cleaning equipment

1633 WEST 134th. STREET GARDENA, CA 90249-2013

TEL: 310 323 1134 FAX: 310 323 8397

WWW.TIMBUCKTOOMFG.COM

© All rights reserved